

## PROGRAMMING AND SETUP PROCEDURE

To program the unit for your application, follow these steps using the 3-button keypad.

1. Press and hold the  button until you see the word *PRESETS* appear (approx 5 sec.)

2. Press the  &  buttons to scroll through the list of standard pipe sizes and schedules.

When the desired pipe is displayed, press the  button to accept that value and proceed to the *Units*

3. When *Units* appears, use the  &  buttons to cycle through the 3 choices of Gallons or Liters. When the desired unit of measure is displayed, press the accept that  button to value and proceed to the *PERCENT ADJUST*

4. When *PERCENT ADJUST* appears, use the  &  buttons to set the correct percentage (see calibration examples on pages 5 & 6). When the desired percentage is displayed, press the  button to accept that value and proceed to the normal operating mode.